



This Connected Device Warranty is a Limited Warranty, subject to the limitations and exclusions set forth herein. TrickleStar will repair or replace the damaged connected devices, at TrickleStar's option, an amount equal to the fair market value of the damaged devices or the original purchase price of the devices, whichever is less, up to the maximum of \$20,000.

The fair market value of the devices shall be the current value of the devices specified in the most recent edition of the Orion Blue Book Online on usedprice.com.

TrickleStar reserves the right to review the damaged Product, the damaged devices, and the site where the damage occurred. All costs of shipping the Product and the damaged devices to TrickleStar for inspection shall be borne solely by the purchaser. TrickleStar reserves the right to negotiate the cost of repairs. If TrickleStar determines, in its sole discretion, that it is impractical to ship the damaged devices to TrickleStar, TrickleStar may designate, in its sole discretion, a repair facility to inspect and estimate the cost to repair such devices. The cost, if any, of shipping the devices to and from such repair facility and of such estimate shall be borne solely by the purchaser.

Damaged devices must remain available for inspection until the claim is finalized. Whenever claims are settled, TrickleStar reserves the right to be subrogated under any existing insurance policies the claimant may have. All above warranties are null and void if:

- The Product in use during the occurrence is not provided to TrickleStar for inspection upon TrickleStar's request at the sole expense of the purchaser.
- TrickleStar determines that the Product has not been installed in accordance with the Installation Requirements, altered in any way or tampered with.
- TrickleStar determines that the damage did not result from the occurrence or that no occurrence in fact took place, the repair or replacement of the damaged devices is covered under a manufacturer's warranty.
- TrickleStar determines that the connected devices were not used under normal operating conditions or in accordance with any labels or instructions.
- The Product is not plugged directly into a receptacle.
- The Product is "daisy-chained" together in serial fashion with other power boards, UPS', other surge protectors or extension cords.
- A three-to two-prong adapter is used.
- The Product is not used indoors. This Product is not for use with aquariums and all other water-related products. Use only indoors and in dry locations.

The Connected Device Warranty only protects against damage to properly connected devices where TrickleStar has determined, in its sole discretion, that the damage resulted from an Occurrence, and does not protect against acts of God (other than lightning) such as flood, earthquake, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low voltage disturbances (i.e. brownouts), non-authorized program, or system devices modification or alteration. This warranty contains the sole warranty of TrickleStar, there are no other warranties, expressed or, except as required by law, implied, including the implied warranty or condition of quality, merchantability or fitness for a particular purpose, and such implied warranties, if any, are limited in duration to the term of this warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

In no event shall TrickleStar be liable for incidental, special, direct, indirect, consequential or multiple damages such as, but not limited to, lost business or profits arising out of the sale or use of any Product, even if advised of the possibility of such damages. This warranty gives you specific legal rights, and you may also have other rights, which may vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damage, so the above limitations may not apply to you.

This warranty is valid only for the original purchaser of the product. All damage claims against the product must be made within 30 days from the date of the occurrence and must be accompanied by a receipt for the damaged devices or the warranty is void.

Warranty is valid in USA and Canada.

MAKING A WARRANTY CLAIM

Go to: www.tricklestar.com and print our claim form and email it to warranty@tricklestar.com


Provide the following information:

- Product part number
- A list of the devices that were connected to the Product at the time of the occurrence
- A list of the devices that were damaged during the occurrence and the extent of the damage
- The date of the occurrence
- Where and when you purchased the Product
- A copy of the original purchase receipt

A Customer Service Representative will then instruct you on how to forward your devices, receipt and Product in use during the "occurrence" and how to proceed with your claim.

COPYRIGHT & DISCLAIMER

© Copyright TrickleStar Inc. All rights reserved. TrickleStar® is a registered trademarks of TrickleStar Ltd. Any typographical, clerical or other error or omission in this document or other documents or information issued by TrickleStar shall be subject to correction without any liability on the part of TrickleStar without notice.



PREMIUM QUALITY FIREPROOF SURGE PROTECTION

The TS0008 incorporates fireproof metal oxide varistors (MOV). The MOVs are encased in ceramic, which is capable of suppressing more energy and dissipating heat faster than traditional MOVs. More importantly, the ceramic casing is fireproof, and therefore capable of preventing fire during abnormal surge conditions.

PRODUCT INFORMATION

TS0004	4 Outlet Advanced PowerTap 2160 J, Coax, Data / Tel / Fax protection, 4C Color box
TS0005	4 Outlet Advanced PowerTap 2160 J, Coax, Data / Tel / Fax protection, Polybag
TS0006	4 Outlet Advanced PowerTap 1080 J, Polybag
TS0008	4 Outlet Advanced PowerTap 1080 J, 4C Color box

FOR TECHNICAL SUPPORT

Toll free : 1-888-700-1098
<http://www.tricklestar.com/support>

INTRODUCTION

The PowerTap provides 4 outlets (1 control, 1 always-on, 2 switched) premium quality surge protection, noise filtering, and a simple, reliable way to automatically reduce the standby power that is consumed by TV and PC accessory devices.



QUICK START INSTALLATION

Follow these easy steps to install your Advanced PowerTap.

1. Plug the PowerTap into a Wall Outlet / Receptacle.
2. Plug a PC or TV into the 'Control' Outlet.
3. Plug a device required to be powered all the time such as a Tivo or Router into the 'Always On' outlet.
4. Plug the devices, which can be switched Off when the 'Control' Device (PC / TV) is Off or in Standby, into the 'Switched' outlets.

NORMAL OPERATION

PC / TV On = Accessories On
 PC / TV Off / Standby = Accessories Off = No Standby Power
 Surge protection is provided to all devices, all of the time.

Switching Threshold

The 'Switching Threshold Switch' – located on the rear of the product, adjusts the Threshold at which the Switched outlets switch On/Off.

The product has 2 preset Switching Thresholds:
 18W typically for Notebook and Netbook PC's
 35W typically for Desktop PC and TV

OVERVIEW

Ground & Surge LED's:
 When the Ground LED is lit, it indicates that the product is correctly grounded. If the Ground LED is not lit, try plugging the product into another power outlet. When the Surge LED is lit, it indicates that the surge protection is functioning correctly.

Always On Outlet / LED

Plug your Tivo, Router, Fax Machine, DSL Modem into this outlet. This outlet remains On all the time and is not switched by the 'Control Outlet'. When the Always On LEDs are lit, it indicates that the Outlet is powered.


Switched Outlets / LED

Plug all other devices into these outlets. These outlets will switch On and Off in conjunction with the device plugged into the 'Control Outlet'. When the 'Switched Outlets' LED is lit, it indicates that the Outlets are powered.

TV INSTALLATION

The TV is plugged into the 'Control' Outlet of the product. The Tivo / HDD recorder should be plugged into the 'Always On' Outlet.


The remaining accessory devices should be plugged into the 'Switched Outlets'.



PC INSTALLATION

The Computer (PC or Mac) is plugged into the "Control" Outlet of the product.

The device requiring always On power (Network Router / External HDD) should be plugged into the 'Always On' Outlet. The remaining accessory devices should be plugged into the 'Switched Outlets'.



INSTALLATION REQUIREMENTS

Power Connections

The Product should only be plugged into a grounded outlet. All connected devices should be plugged directly into the Product. Using any extension cord in conjunction with the product will void all TrickleStar warranties.

Phone / Fax / Modem / Network Connections

Selected product models come with phone / fax / data / coaxial surge protection. Instead of running a connection directly from your phone / fax / computer to the wall jack, you must pass the connection through the protected jacks on the product. Connect your phone / fax / computer line from your wall outlet to the "In" jack on the Product.

Connect a phone cord or network cord into the "Out" jack on the product, and connect the other end of the phone cord to the phone / fax / network jack of the device you want to protect.

If you fail to connect the phone / fax / data / coaxial protection, the Connected Device Warranty will not cover your connected devices. Most modem damage can be prevented if you take the time to connect the phone / fax / data protection. If you have multiple devices that utilize the same phone line, you may daisy chain them from the surge protector, but only using the phone / fax / data protection.

Coaxial Cable Connections

Selected Product models come with coaxial cable surge protection. Instead of running a connection directly from your DSS receiver / TV / VCR / cable box to the wall jack, you must pass the connection through the protected "F" connectors on your product.

Connect your incoming cable / antenna / DSS line to the "Input F" connector on the surge protector. Connect a coaxial cable into the "Output F" connector on the product, and then connect the other end of the coaxial cable to the "Input F" connector of the device you want to protect.

If you fail to use the coaxial cable protection, the Connected Device Warranty will not cover your connected devices. Most TV / VCR damage can be prevented if you take the time to connect the coaxial cable protection.

If you have multiple devices that utilize the same cable/antenna line, you may daisy chain them from the surge protector, but only using the coaxial cable protection.

LED Indication

The "Surge" light should be green when plugged in. If this LED goes off at any time, it means that the Product was sacrificed to protect your devices and should be replaced.

The "Ground" LED should be on when the product is powered on. If this light does not come on when you plug in the Product into a wall outlet, you have a ground-wiring problem and you should contact an electrician to properly ground the outlet. Connecting a Product to an improperly grounded outlet will void all TrickleStar warranties.

All connected devices should be plugged directly into your Product – using any extension cord in conjunction with a Product will void all TrickleStar warranties.

ELECTRICAL AND ENVIRONMENTAL SPECIFICATIONS FOR INDOOR USE ONLY

Voltage	120 VAC +/- 10% 60Hz
Outlets	1 Control Outlet 1 Always-On Outlets 2 Switched Outlets
Power Rating	15A
Surge Protection (TS0004 / TS0005)	144,000 A/2160 J
Surge Protection (TS0006)	72,000 A/1080 J
Switching Thresholds	35W/18W
Operating Temp	0° to 40°C
Storage Temp	-20°C to +60°C
Humidity	5 to 90% N/C

APPROVALS

ELECTRICAL & SAFETY	OTHER
UL (US and Canada)	2002/95/EG (RoHs) 2002/96/EC (WEEE)

PRODUCT WARRANTY

The Product Warranty is 10 years (hereafter referred to as Product Warranty).

TrickleStar warrants to the original purchaser that for the Product Warranty, it shall be free of defects in design, assembly, material, or workmanship, and will repair or replace, at its option, any defective product free of charge.

CONNECTED DEVICE WARRANTY

TrickleStar will repair or replace, at its option, any devices which are damaged by a transient voltage surge / spike or lightning strike, (an "Occurrence"), while properly connected through the Product to a properly wired AC power line through a properly grounded receptacle.

If applicable; the telephone line, and/or network line must be properly connected and installed, and the antenna cable line must also be properly connected and installed, as determined by TrickleStar at its sole discretion.